

Montážní návod / Assembly Instructions HB-CW

A-6pcs



10x40 mm

B1-4pcs



6x30 mm

B2-2pcs



6x40 mm

C-4pcs



5x100 mm

F-1pc



1pc



4pcs



Attention:



ENG

Product is made of high quality beech wood guaranteeing maximum resistance and long service life of the bench.

Like all solid wood products it must not be left in areas of high humidity or damp that will cause natural movement.

Recommended humidity level max. 60%.

Product has NO TREATMENT. Please treat your the worktop with a varnish or oil before assembly including bottom of worktop.


Don't forget to repeat surface treatment each 6 months. This is especially important if situated in an unheated workshop, garage or outbuilding. Varnish (oil) prevents absorption of surrounding moisture.

Wood is a natural product, check and tighten all screws and bolts every 6 months.

To increase stability, the worktop can be screwed to a table.


WARNING!!! - In this case, the table top to which you will screw the worktop will be damaged!!!

Parts	Packing 1	Packing 2	Date	




A+F

Back leg without holes for spindle




Front leg with holes for spindle




Tělo vřetene
Spindle "body"

B1

Spindle with guide rods



Vice jaw



A+F

B2

A+F

Before screwing of vice jaws, be sure that jaw is parallel with worktop .

Hint: Tighten jaws using spindles. Align jaws with bench top and then use B2 screws for attaching jaw to spindles.